

# SIMPLEX+ GUIA RÁPIDO

QGSP\_PT

Sensitivity Indicator

Target ID


\*Left side navigation in notch discrimination and mode selection  
\*Change the value of any setting.

Botão Pinpoint/Confirmar:


\*Pinpoint: Pressione e segure na tela de detecção.

\* Confirme:

1) Função de equilíbrio do solo:

Pressione e segure para equilibrar o solo automaticamente enquanto estiver na configuração do equilíbrio do solo (  ).

2) Rejeitar / aceitar os alvos:

pressione uma vez para rejeitar ou aceitar os alvos enquanto estiver na configuração de discriminação de pontos de eliminação Notch (  ).



Escala ID do Alvo

ID Notches  
(5 Grupos de Ids)

Modos  
(All Metal/Field/Park/Beach)

Indicador de Profundidade Depth

Indicador de Bateria

\* Navegação do lado direito na discriminação notch e seleção de modo  
\* Altere o valor de qualquer configuração.

Sensibilidade acima

Botão Configurações (Settings):  
Cada vez que você pressiona, a próxima configuração na barra será selecionada e seu valor será exibido na tela.

\* Liga / Desliga: Pressione e segure por cerca de 3 segundos.

\* Sensibilidade desativada: Pressione um por um.



## SETTINGS:



Volume: (4 levels, change using + and -).



Ground Balance: Pump the coil up and down while pressing the Pinpoint/Confirm Button to ground balance automatically.



Iron Volume: Adjusts or turns off the volume of the low iron tone (3 levels, change using + and -).



Notch Discrimination: Eliminate unwanted metals from detection such as trash. Each box represents a group of 5 IDs Any combination of these boxes can be rejected or accepted.

### Automatic:

- 1) Swing the search coil over the metal you want to eliminate. The box that represents the group of IDs for that metal will be highlighted in black.
- 2) Press the confirm button.

### Manual:

- 1) An X and a check mark will appear on screen along with a small arrow cursor underneath the ID bar at the top of the screen.
- 2) Move the arrow cursor using the plus (+) and minus (-) buttons and select the box that includes the ID you want to eliminate.
- 3) Press the confirm button. The box will be highlighted in black.



Frequency Shift: Eliminates EMI (3 levels, change using + and -).



Wireless: 0=Off / Channels 1-5 (change using + and -).



Vibration: On/Off (change using + and -).



Brightness: Adjusts the LCD and keypad backlight. 0=Off / 1-4 / A= Auto (lights up only for a short period of time when a target is detected or while navigating the menu and then it goes off).



LED Flashlight: On/Off (change using + and -).

Just turn your detector on, ground balance if you need to and start swinging your coil. Happy metal detecting with the SIMPLEX+!  
For more details, please read the user manual.